IH40
HANDHELD
RFID READER

Accessories Guide

Honeywell

ACCESSORIES

IH25-BR-1

Bracket

For booted CT40; allows holding the mobile computer and charging it simultaneously.

IH25-BR-2

Bracket

For non-booted CT40; allows holding the mobile computer and charging it simultaneously.

IH25-BR-3

Bracket

For CT60; allows holding the mobile computer and charging it simultaneously.

IH25-BR-4

Bracket

For EDA51K; allows holding the mobile computer and charging it simultaneously.

IH40-BR-4

Bracket

For booted CT40; allows holding the mobile computer and charging it simultaneously.

IH25-BR-4

Bracket

For booted EDA51K; allows holding the mobile computer and charging it simultaneously.

IH40-BK-45

Bracket

For booted CT45; allows holding the mobile computer and charging it simultaneously.

IH40-BK-45PB

Bracket

non-booted CT45; allows holding the mobile computer and charging it simultaneously.

CBL-500-120-S00-05

USB Cable (Type-C)

Charging and 056 communication cable for RFID IH25, Type C, 1.2 m.

50155100-001

Wrist Wrap

Wrist wrap for holding.

50129589-001

Battery Pack

Standard battery pack for ScanPal EDA51 & IH25 (Li-ion, 3.8 V, 4000 mAh).

50134176-001

Battery Pack

EDA51 & IH25 (Li-ion, 3.8 V, 4000 mAh). Standard battery pack for ScanPal EDA51 & IH25 (Li-ion, 3.8 V, 4000 mAh) (included with each terminal). For use in North America and Latin America.

IH40-ADP-SLV

IH40 Adapter Sleeve

For CT40-HB-UNVN-X

CHARGERS

CT40-HB-UVN-0

Standard CT40 Non-Booted Home Base

For recharging computer and one spare battery. Kit includes home base and power supply. Power cord must be ordered separately. Supports USB client via USB Type B connector.

CT40-CB-UVN-0

Standard CT40 Non-Booted Charge Base

For recharging up to four computers only. Kit includes 4-bay charger and power supply. Power cord must be ordered separately.

OTHER CHARGERS

IH40 can be charged with any charge dock that a non-booted CT40 / CT45 can be charged with. Other than above two specimen chargers, IH40 is compatible with following list of existing CT40 chargers.

CT40-CB-UVN-0

CT40 non-booted charger

Kit includes 4 bay charger, power supply, must order power cord separately. For recharging up to 4 computers only. 1 for US power cord, 2 for EU power cord, 3 for UK power cord..

CT40-EB-UVN-0

CT40 non-booted charger

Kit includes 4 bay charger, power supply, US power cord. For recharging upto 4 computers only. 1 for US power cord, 2 for EU power cord, 3 for UK power cord..

CT40-HB-UVN-0

CT40 non-booted home base

Kit includes homebase, power supply, must order power cord separately. For recharging computer and a spare battery. Support USB client via USB Type B connector. 1 for US power cord, 2 for EU power cord, 3 for UK power cord.

CT40-NB-UVN-0

CT40 non-booted 4 bay netbase

Kit includes Dock and power supply, must order power cord separately. For Ethernet comms and recharging up to 4 computers only. 1 for US power cord, 2 for EU power cord, 3 for UK power cord..

CT40-DB-UVN-0

CT40 non-booted display dock

Kit includes Display Base, power supply, must order power cord separately. For Charging CT40 only, connection with an external display, and extending I/O for HDMI, Ethernet comm and 3 USB ports.1 for US power cord, 2 for EU power cord, 3 for UK power cord .

Honeywell