

# **CS60-HC Series Companion Scanner**

# Ultra-versatile healthcare scanner with a first-of-its-kind convertible design

Do you need a cordless scanner at the point of care and a corded hands-free scanner in the pharmacy and lab? What if you didn't have to deploy different scanners for different tasks? Introducing the CS60-HC Series Healthcare Companion Scanner, featuring a groundbreaking design that easily converts between corded and cordless operation, handheld and hands-free, as your needs change. As a cordless scanner, the CS60-HC is ultra-portable and pocketable to meet any nurse-carry workflow and offers the latest mobile technology including contactless charging. As a corded scanner, the CS60-HC provides compact scanning for the pharmacy counter, lab station and more. Whether you purchase a corded or cordless model up front, you can change modes at any time for superior investment protection. You get Zebra's industry-leading scanning performance, easier data entry between multiple host applications and seamless disinfectant-ready plastics. And our unique DataCapture DNA and industry-preferred management tools make it easier than ever to integrate, deploy and manage your scanners.



## Adapts to any clinician workflow

### First-of-its-kind convertible design minimizes investment risk

Whether you need a cordless companion scanner paired to a cartmounted cradle, mobile device or in-room workstation at the point of care; a hands-free presentation scanner in the lab; or a corded handheld scanner at the pharmacy, the CS60-HC has you covered. Simply swap the battery and corded USB converter at any time to change between corded and cordless scanning. Add the optional presentation stand or cradle to automatically switch between hands-free and handheld modes. This unparalleled versatility minimizes investment risk as it's easy to meet new workflow needs or redeploy CS60-HC scanners to a different application.

#### Proven scanning performance you can trust

With a high-resolution megapixel sensor and Zebra's exclusive PRZM Intelligent Imaging technology, the CS60-HC easily and accurately captures the many kinds of barcodes commonly used in hospitals including barcodes on patient wristbands, medication vials, IV bags and specimen trays. When you choose the CS60-HC, you get Zebra's world-renowned quality and reliability.

### Effortless multi-tasking with a second programmable button

A second programmable button can be used to instantly toggle between two host applications, such as Electronic Medical Record (EMR) and blood collection applications. With a quick press of the button, clinicians can send data to the right application in the proper format and order.

# Purpose-built housing helps offer maximum protection against the spread of bacteria

Special plastics and IP65 sealing allow for safe wipe-downs with the widest selection of aggressive disinfectants used in today's hospitals. And with a monocoque design, inductive sensing touch buttons and contactless charging, the scanner's crevice-free surface helps eliminate places where germs can hide.

### Safe LED aimer can be used throughout the hospital

Thanks to a highly visible and safe LED aimer, the CS60-HC can be used in the NICU, labor and delivery and mother-baby units where the use of laser aimers is not advised. And the green aimer reduces the likelihood of triggering PTSD episodes.

The CS60-HC Companion Scanner — minimize investment risk with an innovative convertible design that adapts to any workflow. For more information, visit www.zebra.com/cs60-hc

#### Flexible feedback modes — including night mode with vibrate

Choose the right feedback for any environment: a good decode LED, haptic feedback, a beep tone with adjustable tone/volume and Zebra's Direct Decode Indicator that projects illumination on the barcode. In night mode, a quick press of the trigger toggles between an audible beep and vibration. Clinicians instantly know that a medicine vial or wristband was successfully scanned — while disturbing patients as little as possible.

### Doubles as a workstation lamp

The scanner's built-in lamp can illuminate a nurse's workstation, so there's no need to disturb sleeping patients by turning on the overhead lights.

### **Cutting-edge clinical mobility**

#### Qi inductive charging

Support for inductive charging on the CS60-HC eliminates the need for battery contact cleaning and maintenance.<sup>1</sup> While you get the fastest charging times with Zebra's inductive charging solution, you're free to use any off-the-shelf Qi wireless charging pad to charge the CS60-HC.

#### Split-second NFC tap-to-pair

With built-in NFC, the CS60-HC easily pairs with other devices and in-room workstations — no IT support required.

#### Pocketable and wearable for room-to-room mobility

The cordless CS60-HC can be tucked in a scrub pocket and is designed to fit naturally in the hand for easy scanning. Pair the CS60-HC with the optional lanyard and silicone protector to safely and comfortably wear the scanner all shift long.

## Full shift power and beyond

The fully charged battery delivers 18 hours of power — more than enough for a clinician's longest shift. Batteries can be easily replaced without special tools. And a dedicated battery gauge takes the guesswork out of charge status, so clinicians know at a glance when it's time to change or charge a battery.

### Compact cradle fits on any workstation

The presentation cradle has a compact footprint that is elegantly crafted to fit on the most space-constrained workstations — whether mobile or in-room.

#### Extended 330 ft./100 m range

The CS60-HC is a certified BT 5.0 device. With Class 1 Bluetooth, users can roam up to 330 feet/100 m from the host device for greater flexibility.

#### Eliminate Bluetooth Interference with Wi-Fi Friendly Mode

Ensure that your cordless CS60-HC scanners only operate on channels that are not shared with your Wi-Fi network.

### Minimize workflow disruptions with anti-loss tools

Press the cradle's paging button to locate a misplaced cordless CS60-HC in seconds. With Zebra's built-in Virtual Tether functionality, users are alerted when a device is taken out of range, misplaced or unintentionally left out of the cradle for an extended period of time — a helpful reminder to return the CS60-HC to its charger.<sup>2</sup>

### Keep spare batteries on hand with versatile charging options

Multiple charging options make it easy to keep your scanners and spare batteries charged for around-the-clock operation. Four-slot device and four-slot battery chargers are compatible with Zebra's ShareCradle charging system for easy backroom management. And single-slot scanner and battery chargers are ideal on any desk.

### Easy to configure and manage

#### Easily unlock the benefits of UDI

Zebra's UDI Scan+ makes it easy to capture and enter Unique Device Identification (UDI) information into your application. Simply scan the barcode on the medical device packaging. The UDI barcode data is automatically parsed, properly formatted and sent in the right order to the right fields in your EMR or other application. No manual data entry is required.

#### Industry preferred management tools with DataCapture DNA

Only from Zebra, DataCapture DNA is a unique collection of value-add tools that make it easier to deploy, update, troubleshoot, manage and develop applications for your CS60-HC scanners. For example, 123Scan creates a single barcode to stage scanners or update firmware. You can remotely manage your scanners through Scanner Management Service (SMS) or Windows Management Instrumentation (WMI), eliminating the time and cost for onsite visits. And more.

# **CS60-HC Specifications**

Physical Characteristics		
Dimensions	Scanner        0.9 in. H x 1.8 in. W x 4.3 in. D        2.3 cm H x 4.6 cm W x 10.9 cm D        Presentation Cradle        3.5 in. H x 2.1 in. W x 2.4 in. D        9.0 cm H x 5.3 cm W x 6.1 cm D	
Weight	Corded CS60-HC: 2.0 oz. / 58.0 g Cordless CS60-HC: 3.1 oz. / 87.0 g Presentation Cradle: 3.4 oz. / 96.0 g	
Input Voltage Range	Scanner and presentation cradle: 4.5 to 5.5 VDC Host Powered; 4.5 to 5.5 VDC External Power Supply	
Current	Operating current at nominal voltage (5.0V): 400 mA (typical) Standby current (idle) at nominal voltage (5.0V): 90 mA (typical) Presentation Cradle: 450 mA (typical) Standard USB; 600 mA (typical) BC 1.2 USB	
Color	Healthcare white	
Supported Host Interfaces	USB	
Keyboard Support	Supports over 90 international keyboards	
FIPS Security Certification	Certified compliant with FIPS 140-2	
User Indicators	Direct Decode Indicator, Good Decode LEDs, beeper (adjustable tone and volume), haptic feedback on decode, capacitive trigger with haptic and audible feedback, dedicated battery gauge, dedicated Bluetooth LED	
Performance Chara	octeristics	
Motion Tolerance (handheld)	Up to 20 in. / 51 cm. per second for 13 mil UPC in optimized mode	
Light Source	Aiming Pattern: circular 525nm true green LED	
Illumination	(1) warm white LED	
Imager Field of View	45° H x 34° V nominal	
Image Sensor	1280 x 960 pixels	
Minimum Print Contrast	20% Minimum Reflective Distance	
Skew Tolerance	+/- 60°	
Pitch Tolerance	+/- 60°	
Roll Tolerance	0° - 360°	
Minimum Element Resolution	Code 39 - 5.0 mil	
User Environment		
Operating Temp.	32° F to 122° F / 0° C to 50° C	
Storage Temp.	-40° F to 158° F / -40° C to 70° C	
Humidity	5% to 95% RH, non-condensing	
Drop Specification	Designed to withstand multiple drops at 5.0 ft./1.5 m to concrete	
	Designed to withstand 250 tumbles in 1.5 ft./0.5 m	
Tumble Specification	tumbler (1 tumble = $0.5$ cycle)	

Approved Cleaners	Disinfectant Ready. Refer to the product reference guide for the complete list of approved cleaners.
Electrostatic Discharge (ESD)	Scanner and cradle: ESD per EN61000-4-2, +/-15 KV Air, +/-8 KV Direct, +/-8 KV Indirect
Ambient Light Immunity	0 to 10037 foot candles / 0 to 108,000 Lux
Radio Specifications	i
Bluetooth Radio	Standard Bluetooth Version 5.0 with BLE: Class 1 330ft. (100m) and Class 2 33ft. (10m), Serial Port and HID Profiles
Adjustable Bluetooth Power	Output power adjustable down to negative 10 dBm in 8 steps
Battery	
Battery Capacity/Type	735 mAh Lithium Polymer battery
Scans Per Battery Charge <sup>3</sup>	13,000 scans
Operating Time Per Full Charge <sup>3</sup>	18 hours
Battery Charge Time	e (from empty)
Standard USB	Full Charge: 8 hours
BC1.2 USB	Full Charge: 6 hours
Regulatory	
Environmental	EN 50581:2012 EN IEC 63000:2018
Electrical Safety	IEC 62368-1 (Ed.2) EN 62368-1:2014/AC:2015
LED Safety	IEC 62471:2006 (Ed.1.0) EN 62471:2008 (LED)
EMI/RFI	EN 55032:2015/AC:2016 (Class B) EN 55035:2017 EN 61000-3-2:2014 (Class A) EN 61000-3-3:2013 47 CFR Part 15, Subpart B, Class B
Accessories	
Cordless Accessories	Presentation cradle, spare battery, 4-slot scanner ShareCradle, 4-slot battery ShareCradle, lanyard
Corded Accessories	Gooseneck Intellistand (weighted and standard), cup, corded USB converter
Symbol Decode Cap	pability
1D	Base 32 (Italian Pharma), Codabar/NW7, Code 11, Code 39, Code 93, Code 128, GS1 DataBar, I 2 of 5, Korean 3 of 5, MSI Plessey, UPC/EAN
2D	Aztec, Composite Codes, DataMatrix, Dotted DataMatrix, Dotcode, Han Xin, MaxiCode, PDF417, Micro PDF417, Postal Codes, QR Code, Micro QR, TLC-39, SecurPharm
OCR	OCR-A, OCR-B, MICR, US Currency
Pofor to Product Poforone	e Guide for complete list of symbologies.

# Applications and users

# Healthcare

# applications

- Positive Patient
  Identification (PPID)
- Medicine administration
- Inventory
- management • Pharmacy
- Electronic medical
- record access
- Specimen collection Phlebotomy

## Healthcare users

- Clinicians
- Technicians
- Pharmacists
- Admissions personnel

Decode Ranges (Typical) <sup>4</sup>		
Symbology/Resolution	Near/Far	
Code 39: 5 mil	2.4 in./6.1 cm to 9.5 in./24.1 cm	
Code 39: 20 mil	2.5 in./6.4 cm to 26.0 in./66.0 cm	
Code 128: 5 mil	2.8 in./7.1 cm to 9.0 in./22.9 cm	
PDF 417: 6.7 mil	2.4 in./6.1 cm to 8.0 in./20.3 cm	
UPC: 13 mil (100%)	1.8 in./4.6 cm to 19.5 in./49.5 cm	
Data Matrix: 10 mil	2.9 in./7.4 cm to 8.0 in./20.3 cm	
QR: 20 mil	1.2 in./3.0 cm to 14 in./35.6 cm	

#### **Environmental Compliance**

#### Environment

· RoHS Directive 2011/65/EU; Amendment 2015/863

• REACH SVHC 1907/2006

For a complete list of product and materials compliance, please visit www.zebra.com/environment

#### Warranty

Subject to the terms of Zebra's hardware warranty statement, the CS6080-HC scanner and CR6080-HC cradle are warranted against defects in workmanship and materials for a period of Three Years from the date of shipment. Complete Zebra hardware product warranty statement: <a href="http://www.zebra.com/warranty">www.zebra.com/warranty</a>

#### **Recommended Services**

Zebra OneCare Essential and Select: Maximize Zebra device availability, device value and operational efficiency with these fully-featured support services that set the industry bar for support.

#### Footnotes

- Contactless inductive charging is supported when a battery is inserted in the CS60-HC. Spare batteries and battery chargers have charging contacts and cannot be charged with a wireless charge pad.
- Virtual Tether alerting is supported on the scanner today, with planned availability for alerting on the cradle via a free firmware download.
- 3. Simulated checkout profile of 1 scan every 5 seconds
- 4. Printing resolution, contrast, and ambient light dependent

#### DataCapture DNA

DataCapture DNA is a suite of highly intelligent firmware, software, utilities and apps exclusively engineered to add functionality and simplify the deployment and management of Zebra scanners. For more information about DataCapture DNA and its applications, please visit www.zebra.com/datacapturedna





NA and Corporate Headquarters +1 800 423 0442 inquiry4@zebra.com Asia-Pacific Headquarters +65 6858 0722 contact.apac@zebra.com EMEA Headquarters zebra.com/locations contact.emea@zebra.com Latin America Headquarters +1 847 955 2283 la.contactme@zebra.com

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2020 Zebra Technologies Corp. and/or its affiliates. Part number: SS-CS60 08/26/2020